

Replacement parts list

<u>Part No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Description</u>
293050D	Vertical sash assembly-6 Foot steam	31877	Remote control service fixture-
29592	Vertical sash assembly-5 Foot generic	31878	Remote control service fixture-
31879	Cold water gooseneck	29205	Vertical sash assembly-4 Foot
32165	DI/DW gooseneck	2930308	Combination sash assbly-6 foot
295870A	Combination sash assbly-5 Foot	32163	CW gooseneck w/vacuum breaker
295866	Glass panel assbly for combination sash only	32018	Aspirator
31868	48" x 30" x 1" epoxy worksurface	11790	¾ stainless steel plug button
34778	60" x 30" x 1" epoxy worksurface	295818B	Light box- 4 and 5 foot
31869	72" x 30" x 1" epoxy worksurface	2930315	Light box-6 foot
31870	3" x 6" cupsink	292078	Worksurface airfoil- 4 foot
31871	3" x 9" cupsink	295583	Worksurface airfoil- 5 foot
31872	3" x 11" cupsink	293078	Worksurface airfoil- 6 foot
295860A	Airwatch II Fume Hood alarm and control panel	295908A	Light box assbly- 4 & 5 foot
31873	Remote control service fixture air	295839	Light glass assbly- 4 & 5 foot
31874	Remote control service fixture vacuum	2930314	Light box assbly- 6 foot
31875	Remote control service fixture gas	2930313	Light glass assbly- 6 foot
31876	Remote control service fixture DI/DW	2920322	Top front bypass-4 foot
		2920321	Top rear bypass- 4 foot
		295812D	Top front bypass- 5 foot
		295811D	Top rear bypass- 5 foot
		2930312	Top front bypass- 6 foot
		2930311	Top rear bypass- 6 foot